CORSAIR
46221 Landing Parkway • Fremont • California • 94538 • USA

© 2012 Corsair Components, Inc. All rights reserved.
All rights reserved. Corsair, the sails logo, and Dominator are registered trademarks, and AirFlow is a trademark in the United States and/or other countries.
All other trademarks are the property of their respective owners. Product may vary slightly from those pictured. Document Number: 49-001960 rev AA

CORSAIR



DOMINATOR® PLATINUM

QUICK START GUIDE

01



Insert the memory module(s) into the memory socket

- Insérez le ou les modules de mémoire dans le connecteur de mémoire.
- Inserire i moduli della memoria nella presa con attacco per la memoria
- Stecken Sie das Speichermodul in den Speichersockel ein
- Inserte los módulos de memoria en el zócalo correspondiente
- Вставьте модули памяти в разъемы памяти

02



Attach the legs to the fan

- Attachez les pieds au ventilateur
- Collegare le gambe alla ventola
- Bringen Sie die Beine am Lüfter an
- Fije las patas al ventilador.
- Прикрепите ножки к вентилятору

03



Mount the fan to the memory socket

- Fixez le ventilateur au connecteur de la mémoire
- Montare la ventola sull'alloggiamento memoria
- Befestigen Sie den Lüfter am Speichersockel
- Monte el ventilador en el zócalo de memoria
- Установите вентилятор на разъем памяти

04



Without the Corsair Link™ Lighting Node

Connect the LED cable to the female connector of the fan Y-cable

- Connectez le câble LED au connecteur femelle du câble en Y du ventilateur
- Collegare il cavo a LED al connettore femmina del cavo Y della ventola
- Verbinden Sie das LED-Kabel mit der Buchse des Y-Lüfterkabels
- Conecte el cable LED al conector hembra del cable en Y del ventilador
- Подключите кабель светодиодной подсветки к гнездовому разъему Y-образного кабеля вентилятора

04

With the Corsair Link Lighting Node

Connect the LED cable to the Corsair Link lighting node

Note: Please refer to the Corsair Link software for instructions on how to customize LED color

- Connectez le câble LED au Corsair Link lighting Node
  Remarque : Veuillez consulter les instructions du logiciel Corsair Link pour découvrir comment personnaliser les couleurs LED
- Collegare il cavo a LED al nodo di illuminazione Corsair Link™
  Nota: Fare riferimento al software Corsair Link per le istruzioni su come personalizzare il colore LED
- Verbinden Sie das LED-Kabel mit dem Corsair Link Knoten für Lichteffekte
  Hinweis: Anleitungen dazu, wie die LED-Farben angepasst werden können, finden Sie in der Corsair Link Software
- Conecte el cable LED al nodo de iluminación Corsair Link
  Nota: Consulte el software de Corsair Link para obtener indicaciones sobre cómo personalizar el color del LED
- Подключите кабель светодиодной подсветки к узлу управления подсветкой Corsair
  Примечание. Обратитесь к инструкциям программного обеспечения Corsair Link по настройке цвета светодиодной подсветки

05



Connect the fan cable to a motherboard fan header

- Connectez le câble du ventilateur au connecteur du ventilateur de la carte mère
- Collegare il cavo della ventola a un connettore della ventola sulla scheda madre
- Verbinden Sie das Lüfterkabel mit der Lüfter-Stiftleiste auf dem Mainboard
- Conecte el cable del ventilador a un cabezal del ventilador de la placa base
- Подключите кабель вентилятора к разъему вентилятора на материнской плате